HOW TO PUT COMPACT ON LEGS

Step 1a: Undo ratchets and sleeves



Step 2a: Undo the bolts



Step 1b: Undo ratchets and sleeves



Step 2b: Undo the bolts



Step 3a: Take off the bracket plate



Step 4a: Position each leg into the slot sleeve



Step 3b: Take off the bracket plate



Step 4b: Position each leg into the slot sleeve



Step 5: Approx 5 turns each leg if on your own with the supplied manual ratchet handle inserted on each leg. For more stability we recommend fastening the Hex head bolts into position. Ensure all legs are level unless on uneven ground.



Step 6: Reverse all of the above to load onto Utility again.

